

Wiring for Burner Controller L8124E

ETC101 AQUASTAT

"TT Only" screws must be wired.
 "24v" screws are optional,
 to be used with equipment
 not compatible with power
 stealing aquastats.

